

# ONE POINT LESSON: RULES OF TARPING STATION



**TRUCKERS MUST FOLLOW THE FOLLOWING RULES  
WHEN USING TARPING STATION.**

**This Gate will not open unless catwalk platforms are moved against trailer. Platforms on each side must be against trailer.**



**Platform is moved IN and OUT with this Switch located on the Operator Panel located on exit end – driver side**

**This gate – located at rear of trailer – must be down across back of trailer.**